

# Accessory & Option Parts

## for All Category



50Ω Terminator  
**TA-57**  
(DC-1GHz,VSWR1.1)



GP-IB cable(2m)  
**CB-2420P**  
RS-232C cable(2m)  
**CB-2530S**



Banana plug-alligator clip(1m)  
**CA-46A**

Banana plug-alligator clip cable  
**CA-48P** (850mm)


BNC-BNC(1m)  
**CA-43**

BNC-BNC(1.5m)  
**CA-43F**

BNC-BNC(2m)  
**CA-43Y2**


BNC-alligator clip(1m)  
**CA-41**

Dual banana plug-alligator clips(1m)  
**CA-36**



GP-IB Interface  
**IF-10**  
RS-232C Interface  
**IF-20R**

## for Oscilloscope



150MHz Attenuator probes  
**PC-59**  
(X10)

60MHz Attenuator probes  
**PC-54**  
(X10,X1)

50MHz Attenuator probes  
**PC-53**  
(X10,Read out possibility)

100MHz Attenuator probes  
**PC-52**  
(X10,X1)

150MHz Attenuator probes  
**PC-51**  
(X10,Read out possibility)

100MHz Attenuator probes  
**PC-40**  
(X100)

BNC-BNC Attenuator cable  
**PC-26**  
(X10,Read out possibility)

60MHz Attenuator probes  
**GTP-060A**  
(x10, x1)

100MHz Attenuator probes  
**GTP-100A**  
(x10, x1)

150MHz Attenuator probes  
**GTP-150A**  
(x10, x1)

250MHz Attenuator probes  
**GTP-250A**  
(x10, x1)


Panel covers  
**MD-95**  
(For DCS-8300/7000 Series,CS-5300/5400 Series)



Pouch  
**MC-78**



Scope Cart  
**MB-87**  
(Maximum load 12kg)



Rack Mount Adapter  
**RK-400E** EIA  
(For DCS-7040/7020,CS-5400 Series,CS-4135A/4125A)

## for Power Supply



D sub-modular connector  
**TA-60**

Modular Cable  
**CB-0603S** (0.3m)  
**CB-0615S** (1.5m)  
**CB-0630S** (3m)  
**CB-06100S** (10m)  
(For PAR-H/PAR-HL/IF-41RS Series)



Remote Controller  
**RT-63**  
(For PAR-H Series)

**RT-66**  
(For PXR40-12L)

Application Soft Ware  
**S-PXR21A**  
(For PXR40-12L)

**S-PXR22A**  
(For PXR100-6L)

**S-PXR23A**  
(For PXR200-6L)

Application Soft Ware  
**S-PXR31A**  
(For PXR40-12L)

**S-PXR32A**  
(For PXR100-6L)

**S-PXR33A**  
(For PXR200-6L)

EXT I/O Mount Unit  
**OP-12**  
(For PD-A/AD Series,factory option)

GP-IB Adapter  
**GB-600B**  
(For PA-B/PD/PS/PT Series)

Cable for GP-IB Adapter  
**OP-18-PAB**  
(For PA-B Series)

**OP-18-PD**  
(For PD Series)

**OP-18-PS**  
(For PS Series)

**OP-18-PT**  
(For PT Series)

2.5m Power cable  
**CW-0125N**  
(For PU Series full rack size)

RS232C(DB-9)RJ-45(8pin)Modular Cable  
**CT-080920S1**  
(For PU Series)

RS232C(DB-25)RJ-45(8pin)Modular Cable  
**CT-082520S1**  
(For PU Series)

RS485(DB-9)RJ-45(8pin)Modular Cable  
**CT-080920S2**  
(For PU Series)

Additional serial link cable  
**CB-0805S** (0.5m)  
(For PU Series)

**CB-0820S** (2m)  
(For PU Series)

**CB-0850S** (5m)  
(For PU Series)

## for AVC & Digital



**RT-62A**  
(Remote correspondence part for VT-182,CG-951/952/935N/935P,VT182 also requires OP-4)

**RT-150**  
(For SG-5000 Series)

Loop Antenna  
**LU-100A**  
(For SG-5000 Series)

Remote terminal  
**OP-4**  
(Required to connect RT-62A to VT-182)

Rack Mount Adapter  
**OM-13**  
(For V-1200)

**OM-15**  
(For VA-2230A)

**OM-16E**  
(For DA-3400)

Option Filter  
**OF-1-6**  
(For VA-2230A)



GP-IB Interface Card  
**IF-30GP**  
(For PDS Series)

RS-232C Interface Card  
**IF-30RS**  
(For PDS Series)

Analog Control Card  
**IF-30ANA**  
(For PDS Series)

GP-IB/USB Interface Card  
**IF-41GU**  
(For PW-A Series)

RS-232C Interface Card  
**IF-41RS**  
(For PW-A Series)

USB Interface Card  
**IF-41USB**  
(For PW-A Series)

GP-IB Interface Card  
**IF-50GP**  
(For LW Series)

USB Interface Card  
**IF-50USB**  
(For LW Series)

GP-IB Interface Card  
**IF-60GP**  
(For PSF Series)

USB/RS-232C Interface Card  
**IF-60RU**  
(For PSF Series)

Guard cap  
**OP-20GC**  
(For PA-B Series)

Handle kit  
**HK-10**  
(For PSF Series)

Rack Mount Adapter  
**RM-608J**  
(For PA-B,PW-A Series,GP-600B)


EIAJ Rack Mount Adapter  
**RM-608E**  
(For PA-B,PW-A Series,GP-600B)

Rack mounting metal fittings (for one unit)  
**RJ-608-GP**  
(For GP-600B)

Rack mounting metal fittings (for two units)  
**RJ-608-PA**  
(For PA-B Series)

Rack mounting metal fittings (for three units)  
**RJ-608-PW**  
(For PW-A Series)

Blank panel  
**RB-608A/B/C/D/E**  
(For RM-608J/E 1/2,1/3,1/4,1/6,1/12)



Protective Holster  
**MC-590A**  
(For DL-92)

**MC-590B**  
(For DL-94)



4-wire cable  
**KC-01**  
(For DL-2050/2051)

Rack Mount Adapter  
**OM-20E**  
(For DL-2050/2051/2040)